

Innovation at the right price

User information sheet CS 302



I) Principle use

Slide the slider to deploy the blade.



During the cut ensure the slider is released (the blade is kept deployed by friction of the material being cut).



Thus when exiting the material (as the slider is not held out) the blade automatically retracts safely.



Innovation at the right price

User information sheet CS 302

II) Main applications

 ★	 ★	 ★★★★	 ★★★★★	 ★★★	 ★
Stretch film thickness up to 30µm	Straps, plastic foils, composites, textiles.	Corrugated packaging	Cardboard Single ply up to 4mm thick	Cardboard double ply up to 8mm thick	Cardboard sheet up to 2mm thick.

This safety knives is ambidextrous :

The knives can be used by right & left-handed users:
Invert the blade for left hand use


III) Changing the blade

1  Squeeze the two tabs at the rear of the unit to unlock	2  Pull out the slider pad	3  Remove the entire slider block and remove the blade
4  Place the new blade (invert to change from right to left handed)	5  Insert the slider block & 'click' close the two tabs - KEEP HANDS CLEAR OF THE BLADE as the blade may spring out slightly	6  Your knife is ready to use!

+ For greater safety: Discover our accessories

Zicou :Retractable Line

Sharps Bins - Safely dispose of used blades



Do not lose your safety knife !

