

Innovation at the right price

User information sheet CS 2010 / CS 2070 Series



I) Principle use

Slide the slider to deploy the blade.



During the cut ensure the slider is released (the blade is kept deployed by friction of the material being cut).



Thus when exiting the material (as the slider is not held out) the blade automatically retracts safely.



Innovation at the right price

User information sheet CS 2010 / CS 2070 Series

II) Changing the blade

These safety knives are ambidextrous :

The knives can be used by right & left-handed users (Invert the blade for left hand use)

1  Press the two tabs on the rear end cap to release the cap	2  Pull the mono block slider to the rear & completely withdraw	3  remove the used blade and discard safely
4  Locate the new blade by placing on the magnets with centre hole engaged (invert blade to change from right to left hand)	5  Replace the mono block slider	6  'Click' the end cap into place - the knife is ready to use !

III) Main applications

 ★★★★	 ★★★★	 ★★★★	 ★★★★
Corrugated packaging	Cardboard single ply up to 4 mm thick	Cardboard double ply up to 8 mm thick	Cardboard triple ply 12 to 15 mm thick CS 2070 Only
 ★★	 ★	 ★★	 ★
Cardboard 4 ply >15mm CS 2070 Only	Straps, plastic foils, composites, textiles.	Plain card up to 2mm thick	Stretch film thickness up to 30µm.

Innovation at the right price

User information sheet CS 2010 / CS 2070 Series

IV) Setting the output length of blade



Personalise your CS 2010 / CS 2070 by choosing your Slider and your maximum length of blade!

CS 2010 :



Indexer with all 4 notches
maximum blade
length = 4 mm



3 notches = 8mm



2 notches = 12 mm



1 notches = 15 mm



Without Indexer = 16 mm

CS 2070 :



Indexer with all 4 notches
maximum blade
length = 14 mm



3 notches = 16mm



2 notches = 18 mm



1 notches = 20 mm



Without Indexer = 22 mm

For greater safety: Discover our accessories

BH01: Cordoflex Belt Holster
Clips to the belt or the belt loops through.



Do not lose your safety knife !

Sharps Bins - Safely dispose of used blades

